

HOGTUNES

Audio Solutions For The Great American Cruiser

INSTALLATION INSTRUCTIONS

Hogtunes Rear-RM Grills Fit 2014+ Factory Rear Speaker Pods and Can Also Be Used If Installing Speakers In Factory Lower Speaker Adaptors For Air Cooled Bikes

- Step #1: Make sure your ignition switch stays in the "OFF" position.
- Step #2: Remove the factory rear speaker grills by undoing the 4 "torx" screws on the front of the grills. With all 4 screws removed, the factory grills will now come out of the factory rear speaker "pod".
- Step #3: Set the new grills in place, and using the factory screws removed earlier, secure the grill to the "pod" so the screws also go through the mounting holes in the speakers. Note: The factory rubber "nutserts" on the rear pod side can be finicky. It's a good idea to get all 4 grill screws "started" and then get each one snug. Gradually tighten each one down making sure all 4 screws holding the grill down are secure!

NOTE: You can customize these grills by carefully "breaking" the adhesive that holds the trim and mesh together on the back side of the grill. The trim is easily painted, and the metal mesh is thick enough that it should not warp during power coating, polishing, chroming or other similar processing.

REAR-RM GRILL

2014+ ULTRA MODELS METAL MESH GRILLS

Hogtunes Contact Information

Email: techsupport@hogtunes.com

USA Tel: 608-554-7631 - Canada Tel: 705-719-6361